

EOG 200 Cartridge Dryer Installation Instructions:

- 1) Using a cordless drill or powered screw driver, install screw through canister clip; lightly tighten.
- 2) Slide O-ring under clip and align with lower hole dimple.
- 3) Install second screw through clip and O-ring. Tighten screws so clip is solid and canister is held vertically.
- 4) Remove enclosure cover of EOG, if not done already.
- 5) Remove original clear intake hose from CD cell and discard.
- 6) Install the supplied longer intake hose to CD cell and route out and around the back of the enclosure.
- 7) Remove the cap covering the canister's barbed fitting and attach the intake tube to it.

WARNING!
High Voltage!

Be sure to disconnect power to EOG 200 unit before servicing.

